
mcu-uuid-telnet

Simon Arlott

Dec 04, 2022

CONTENTS

1	Description	1
2	Purpose	3
3	Dependencies	5
4	Contents	7
5	Resources	11

**CHAPTER
ONE**

DESCRIPTION

Microcontroller telnet service

**CHAPTER
TWO**

PURPOSE

Provides access to a console shell as a telnet server (using the [RFC 854 protocol](#)).

CHAPTER
THREE

DEPENDENCIES

- [mcu-uuid-console](#)

Refer to the `library.json` file for more details.

CONTENTS

4.1 Usage

```
#include <uuid/telnet.h>
```

Create a `uuid::telnet::TelnetService` and call `start()`.

Call `loop()` regularly and when WiFi connectivity is available connections will be accepted.

Call `uuid::console::Shell::loop_all()` regularly to process open connections.

The binary, echo and suppress go ahead telnet options will be negotiated.

4.1.1 Example

```
#include <Arduino.h>
#ifndef ARDUINO_ARCH_ESP8266
# include <ESP8266WiFi.h>
#else
# include <WiFi.h>
#endif

#include <memory>
#include <string>
#include <vector>

#include <uuid/common.h>
#include <uuid/console.h>
#include <uuid/telnet.h>

using uuid::read_flash_string;
using uuid::flash_string_vector;
using uuid::console::Commands;
using uuid::console::Shell;

static std::shared_ptr<Commands> commands = std::make_shared<Commands>();
static uuid::telnet::TelnetService telnet{commands};

void setup() {
    commands->add_command(flash_string_vector{F("pinMode")},
```

(continues on next page)

(continued from previous page)

```

flash_string_vector{F("<pin>"), F("<mode>")},

[] (Shell &shell, const std::vector<std::string> &arguments) {
    uint8_t pin = String(arguments[0].c_str()).toInt();
    uint8_t mode;

    if (arguments[1] == read_flash_string(F("INPUT"))) {
        mode = INPUT;
    } else if (arguments[1] == read_flash_string(F("OUTPUT"))) {
        mode = OUTPUT;
    } else if (arguments[1] == read_flash_string(F("INPUT_PULLUP")))
↳ {
        mode = INPUT_PULLUP;
    } else {
        shell.println(F("Invalid mode"));
        return;
    }

    pinMode(pin, mode);
    shell.printf(F("Configured pin %u to mode %s"),
                 pin, arguments[1].c_str());
},
[] (Shell &shell, const std::vector<std::string> &current_arguments,
     const std::string &next_argument)
    -> const std::vector<std::string> {
    if (current_arguments.size() == 1) {
        /* The first argument has been provided, so return
         * completion values for the second argument.
        */
        return {
            read_flash_string(F("INPUT")),
            read_flash_string(F("OUTPUT")),
            read_flash_string(F("INPUT_PULLUP"))
        };
    } else {
        return {};
    }
}
);

commands->add_command(flash_string_vector{F("digitalRead")},
                      flash_string_vector{F("<pin>")},

[] (Shell &shell, const std::vector<std::string> &arguments) {
    uint8_t pin = String(arguments[0].c_str()).toInt();
    auto value = digitalRead(pin);

    shell.printf(F("Read value from pin %u: %S"),
                 pin, value == HIGH ? F("HIGH") : F("LOW"));
}
);

```

(continues on next page)

(continued from previous page)

```

commands->add_command(flash_string_vector{F("digitalWrite")},
    flash_string_vector{F("<pin>"), F("<value>")},

[] (Shell &shell, const std::vector<std::string> &arguments) {
    uint8_t pin = String(arguments[0].c_str()).toInt();
    uint8_t value;

    if (arguments[1] == read_flash_string(F("HIGH"))) {
        value = HIGH;
    } else if (arguments[1] == read_flash_string(F("LOW"))) {
        value = LOW;
    } else {
        shell.println(F("Invalid value"));
        return;
    }

    digitalWrite(pin, value);
    shell.printf(F("Wrote %s value to pin %u"),
        arguments[1].c_str(), pin);
},

[] (Shell &shell, const std::vector<std::string> &current_arguments,
    const std::string &next_argument)
    -> const std::vector<std::string> {
if (current_arguments.size() == 1) {
    /* The first argument has been provided, so return
     * completion values for the second argument.
    */
    return {
        read_flash_string(F("HIGH")),
        read_flash_string(F("LOW"))
    };
} else {
    return {};
}
}

commands->add_command(flash_string_vector{F("help")},
[] (Shell &shell, const std::vector<std::string> &arguments) {
    shell.print_all_available_commands();
}
);

commands->add_command(flash_string_vector{F("exit")},
[] (Shell &shell, const std::vector<std::string> &arguments) {
    shell.stop();
}
);

telnet.start();

```

(continues on next page)

(continued from previous page)

```
WiFi.persistent(false);
WiFi.mode(WIFI_STA);
WiFi.begin("SSID", "password");

Serial.begin(115200);
}

void loop() {
    uuid::loop();
    telnet.loop();
    Shell::loop_all();
    yield();
}
```

RESOURCES

5.1 Change log

5.1.1 Unreleased

5.1.2 0.2.0 – 2022-12-04

Upgrade version of `uuid-console`.

Changed

- Use version 3.x.x of `uuid-console`.

Fixed

- Potential for `TelnetStream` to be destroyed before the `Shell` using it stops when lowering the maximum number of connections.

5.1.3 0.1.5 – 2022-11-26

Upgrade version of `uuid-console`.

Changed

- Use `PSTR_ALIGN` for flash strings.
- Use version 2.x.x of `uuid-console`.

5.1.4 0.1.4 – 2022-10-29

Upgrade version of `uuid-console`.

Changed

- Use version 1.x.x of `uuid-console`.

5.1.5 0.1.3 – 2022-07-12

Upgrade version of `uuid-console`.

Changed

- Use version 0.9.x of `uuid-console`.

5.1.6 0.1.2 – 2021-04-18

Upgrade to PlatformIO 5.

Changed

- Use PlatformIO 5 dependency specification.

5.1.7 0.1.1 – 2021-01-17

Upgrade to the latest version of the dependencies for static initialization and deinitialization fixes.

5.1.8 0.1.0 – 2019-09-16

Initial development release.

Added

- Telnet listening service.
- Telnet stream handler with option negotiation.
- Use of TCP keepalives to timeout open connections.
- Configurable idle timeout.
- Configurable write timeout.